




Switch

Training Bindings

USER MANUAL

1. SIZE AND HEELCUP ADJUSTMENT **S/M/L**

- Remove screws [2a] and bring the heelcup in your preferred position.
- Toes and heel should reach the edges of the board. If your boot is shorter, make sure the distance from frontside edge to toes is as big as the distance from heel to backside edge.



2. TOE STRAM POSITIONING

Another useful feature for an ideal size adaption is to fix the toe strap in it's 2 positions.

- Unfix toe and tooth strap in the front by pressing them down.
- Bring the straps in your preferred position (front/rear) and pull them up again.




3. MOUNTING ON BOARD

- Select your stance on the board and put the bindings in place, buckles facing outwards.
- Try to center the binding on your board.
- Angles can be adjusted in increments of 3°
- Screw down the mounting screws.

4. RAMPS ADJUSTMENT

They are independent of each other! It happens that you close the ramps by accident.

1. To open them, use a flat screwdriver.
2. Find a break between to parts on the bottom of a base.
3. Push a flat screwdriver there and twist it.



5. BEFORE TRAINING...


- If you are not familiar with mounting your softbinding contact your local dealer.
- The bindings should be mounted and maintained only by an authorized dealer.
- A mechanic, prior to each season and after 15 to 20 days of use, should inspect them.
- Inspect your equipment every time before you use it. Periodically inspect and tighten loose mounting hardware (screws) if necessary or consult your dealer.
- These bindings are only made and constructed for trainers.
- Training involves a significant risk of serious personal injury to any part of the user's body, property damage and can even cause death. When done properly and under control, these risks can be greatly reduced. Children using the product should do so only with competent adult supervision. Train within your ability level. Follow the safety rules and use your common sense when you train.
- These bindings are non-releasable. They are designed this way, and when mounted properly, should not release and as such they do not protect against any type of injury to any part of the user's body, including wrists, ankles, knees, shoulders and head.

6. STEPPING IN

- Always step in with the front foot first
- Close and tighten the straps

8. STEPPING OUT

- First step out with the back foot
- Open the binding by pushing the opening lever



WARRANTY CONDITIONS

The manufacturer guarantees unobjectable material and immaculate production for 24 months, beginning from the day of purchase, to the original purchaser to the following conditions:

- Complaints, which are due to faults of material or manufacturing, will be compensated by the instructed Service-centre free of charge.
- The transport will be affected on the buyer's account and on his own risk.
- Complaints have to be reported immediately. The claim to warranty will become invalid if the product has been altered, modified or tempered by the buyer or third parties.
- Damages caused by negligence, accident, unreasonable use, or by other causes unrelated to defective materials or workmanship, as damage as a result of normal wear and tear or poor maintenance as well as products not inspected by the dealer.
- We reserve the right to repair or exchange defective parts. The exchanged parts become our property.
- The warranty time will not be prolonged or renewed in case compensation has been effected.
- A reduction of the manufacturer considers an exchange or a repair not to be adequate.
- The claim of compensation with regard to the following damages is, as long as they are due to gross negligence, excluded.

SIZES:

Barefoot:

EU 38-45, Womens US 7.5 - 12+, Mens US 5 - 12.

Shoes:

EU 35-43, Womens US 4 - 12, Mens 3.5 - 10

Bindings weight: 2kg

ADDRESS:

Jakub Pacut Switch Boards
Hallera 121 43-400 Cieszyn
jakub@switch-boards.com
WWW.SWITCH-BOARDS.COM



**SCAN AND
VISIT OUR
WEBSITE**

FOLLOW US ON

  @switch.boards
 @switchsportgear